



# Quick Start Guide EK-P5

# Quick Start Guide EK-P5

1 **Install FTDI USB driver** for the sensor cable.


(<http://www.ftdichip.com/Drivers/VCP.htm>)

2 **Install software** after download from: [www.sensirion.com/USB-viewer](http://www.sensirion.com/USB-viewer)


3 **Connect the USB sensor cable** to the sensor PCB and the PC.

4 **Start up the USB RS485 Sensor Viewer.**


5 Under COM Hardware, **select «RS485/USB Sensor cable».**



6 **Select the sensor product «Sensirion Flow Meters (SF06 Chip)».**




7 **Select COM port** and press «OK». Highest COM port is most often correct.



8 The SF06 Viewer appears. Adjust the **following settings** first:

- Change units to «Pascal».
- Set scale factor to 60.
- Set sampling time to 0.5ms or more.
- Enter command HEX 0x3603.



9 **Press «Run».**

For more information about Sensirion's differential pressure sensors of the SDP800 series, please visit [www.sensirion.com/sdp800](http://www.sensirion.com/sdp800) or contact our technical customer support team:

**SENSIRION AG**

Laubisruetistrasse 50

8712 Staefa

Switzerland

Phone + 41 44 306 40 00

Fax + 41 44 306 40 30

[info@sensirion.com](mailto:info@sensirion.com)

[www.sensirion.com](http://www.sensirion.com)