

TDC7201-ZAX-EVM

User's Guide



Literature Number: SNAU198A
May 2016—Revised May 2016

1	General Description	3
1.1	TDC7201EVM Key Features	3
1.2	TDC7201EVM	4
2	Equipment List	5
3	Quick Start	5
4	Software Installation	6
4.1	Installing the TDC720xEVM GUI	6
4.2	MSP430 Firmware Upgrade (This is only needed for a new Launchpad.)	6
4.3	Checking Connection	7
4.4	Opening the GUI	8
5	Hardware Configuration	9
5.1	TDC7201EVM Connections	9
5.2	Jumpers	12
6	GUI and Operation	12
7	Board Layout	16
8	TDC7201EVM Schematic	19
9	Bill of Materials	21
	Revision History	22

TDC7201-ZAX-EVM

This guide details the use of the TDC7201-ZAX-EVM Evaluation Module (referred to as TDC7201EVM for the remainder of this document). The TDC7201EVM is an evaluation module that allows users to evaluate the operation and performance of the TDC7201 Time-to-Digital Converter. One example application that requires accurate time-to-digital conversion is LIDAR.

The TDC7201EVM connects to the MSP430 LaunchPad evaluation kit for capturing data, and it connects to a user-friendly Graphic User Interface (GUI) to modify the registers and display the data.

1 General Description

1.1 TDC7201EVM Key Features

1. Evaluate TDC7201 Time-to-Digital Converter
2. Connects with MSP430 Launch Pad (MSP-EXP430F5529LP)
3. User-friendly TDC720xEVM GUI interface
4. Connection for START1, START2, STOP1, and STOP2 inputs
5. Powered by MSP430 LaunchPad (no external power needed)

1.2 TDC7201EVM




Figure 1. TDC7201EVM Evaluation Board

2 Equipment List

1. TDC7201EVM
2. TDC720xEVM GUI (<http://www.ti.com/tool/tdc7201-zax-evm>)
3. MSP430 launchpad (<http://www.ti.com/tool/msp-exp430f5529lp>)
4. Micro-USB cable
5. Dual function generator (for example: Tektronix AFG3102 1GS/s, 100MHz)
6. PC with Windows XP or Windows 7
7. 4 BNC-to-SMA cables

3 Quick Start

1. Download and Install TDC720xEVM (GUI) Software. See [Section 4](#) for more information.
2. Connect the USB cable from the MSP430 LaunchPad to the PC.
3. Connect the TDC7201EVM to the MSP430 LaunchPad via J1 and J2.
4. Connect START1 and STOP1 pulses to the TDC7201EVM via J5 and J4. See [Section 5](#) for more information.
5. Launch the GUI. See [Section 6](#) for more information.
6. On the **GRAPH** tab, press the **START GRAPH** button.

4 Software Installation

This section describes software installation, firmware upgrade, and how to update USB Driver.

4.1 Installing the TDC720xEVM GUI

1. Download the TDC720xEVM Software GUI zip file to your desktop. This should be located in <http://www.ti.com/tool/tdc7201-zax-evm>.
2. Unzip the file.
3. Run the **setup.exe** file.
4. Follow the instructions to install the GUI.
5. Once done, you should be able to see the installation in default installation folder; for example, C:\Program Files (x86)\Texas Instruments\TDC720xEVM.

4.2 MSP430 Firmware Upgrade (This is only needed for a new Launchpad.)

1. Open the **TDC720xEVM GUI**.
2. Click on the **Debug** tab.
3. Click on **Update Firmware**.
4. Click **Next** to proceed on the first prompt; read and accept the license agreement, and click **Next** to continue.
5. Choose **Select Firmware**, and then click **Browse**.
 - (a) Go to the folder where you downloaded the TDC720xEVM GUI. The default install folder is C:\Program Files (x86)\Texas Instruments\TDC720xEVM
 - (b) Find the Firmware folder. It is located within the default installation folder, C:\Program Files (x86)\Texas Instruments\TDC720xEVM\Firmware
 - (c) Select the TDC720xEVM firmware text file.
6. On the MSP430 LaunchPad board, press the **BSL button (S5)** and **connect the MSP430 Launch Pad to your PC** using a **USB cable**. If detected, the text displayed on the Firmware Upgrade tool changes from **No device connected** to **Found 1 device**. See [Figure 2](#).
7. On the MSP430 USB Firmware Upgrade GUI, click **Upgrade Firmware**.
8. Click **Close** when done.




Figure 2. Upgrading MSP430 Firmware

4.3 Checking Connection

1. If you haven't done so, connect the **USB cable** from the MSP430 Launch Pad to your PC.
2. If you haven't done so, connect the **TDC7201EVM** to the MSP430 Launch Pad via J1 and J2 as shown in [Figure 6](#).
3. Open the computer's **Device Manager** . To do this, right-click **My Computer**, click **Properties**, and select **Device Manager**.
4. Scroll down to **Ports (COM & LPT)** and check **TDC7200EVM (COMx)** connection as shown in [Figure 3](#).




Figure 3. Device Manager

4.4 Opening the GUI

1. If you haven't done so, connect the **USB cable** from the **MSP430 Launch Pad** to your **PC**.
2. If you haven't done so, connect the **TDC7201EVM** to the MSP430 Launch Pad via J1 and J2 as shown in [Figure 6](#).
3. Run the TDC720xEVM GUI from the Start Menu. By default, it is located in **Programs\Texas Instruments\TDC720xEVM**.
4. GUI should automatically connect and show the screen depicted in [Figure 4](#).




Figure 4. TDC720xEVM GUI

5 Hardware Configuration

This section describes how to properly set up the connections on the EVM

5.1 TDC7201EVM Connections

1. If you haven't done so, connect the **USB cable** from the **MSP430 Launch Pad** to your **PC**.
2. If you haven't done so, connect the TDC7201EVM to the **MSP430 Launch Pad** via **J1** and **J2** as shown in [Figure 6](#).
3. **Setting the Dual Channel Function Generator:**
 - (a) Set channel 1 of the dual function generator to the following (see [Figure 5](#)):
 - (i) Pulse 1-Cycle
 - (ii) Burst mode
 - (iii) Freq = 40 kHz
 - (iv) Delay = 0 s
 - (v) Amplitude = 3.3 Vpp
 - (vi) Offset = 1.65 V
 - (vii) Duty = 20%
 - (viii) Burst Trigger Source = External
 - (b) Set channel 2 of the dual function generator to the following (see [Figure 5](#)):
 - (i) Pulse 1-Cycle
 - (ii) Burst mode
 - (iii) Freq = 40 kHz
 - (iv) Delay = 19 μ s --> **this is the time-of-flight (TOF)**
 - (v) Amplitude = 3.3 Vpp
 - (vi) Offset = 1.65 V
 - (vii) Duty = 20%
 - (viii) Burst Trigger Source = External




Figure 5. START and STOP Signals Scope Shot

4. **Connecting the Input Signal:**

- (a) Using a USB-to-SMA cable, connect channel 1 of the dual function generator to TDC7201EVM's **START1_EXT** connector (J5).
- (b) Using a USB-to-SMA cable, connect channel 2 of the dual function generator to TDC7201EVM's **STOP1_EXT** connector (J4). See [Figure 6](#).

5. **Connecting the Trigger Input:**

- (a) Connect DTG_TRIG (TP9) to the TRIGG input of the dual function generator. DTG_TRIG is generated by the MCU whenever a new measurement is started by the TDC7201. See [Figure 6](#) and [Figure 7](#).




Figure 6. TDC7201EVM Connection Setup



Figure 7. Tektronix AFG3102 Connections

5.2 Jumpers

The following shows the jumper connection:

1. JP1: Jumper for VCC power
 - (a) Connect Pin 1 to Pin 2 – power VCC via MSP430 (**recommended**)
 - (b) Open Pin 1 and Pin 2 – no connection to VCC via MSP430; need to apply external power
2. JP2: Jumper for CLOCK source
 - (a) Connect Pin 1 to Pin 2 – power VCC via MSP430 (**recommended**)
 - (b) Open Pin 1 and Pin 2 – no connection to VCC via MSP430; need to apply external power

6 GUI and Operation

1. If you haven't done so, open the **TDC720xEVM GUI**. The EVM GUI software can be run by clicking on **Start**, then clicking **All Programs**, **Texas Instruments**, and **TDC720xEVM** and selecting **TDC720xEVM**.
2. Click on the **TDC720x** tab and make sure TDC1 is selected with the register configuration in [Figure 8](#):




Figure 8. Recommended TDC7201:TDC1 Register Configuration

- Click on the **Graph** tab, then click on **START GRAPH**. You should be able to read **19 μ s** (assuming you follow the instructions as specified in [Section 5.1](#)).




Figure 9. Graphing

4. **Calculating Time-of-Flight:**

- In the GUI, click on the **TOF_ONE_SHOT** tab.
- You should be able to see *similar* measurement results register values as shown in [Figure 10](#) (assuming you follow the instructions as specified in [Section 5.1](#)).




Figure 10. Measurement Results

- To calculate the time-of-flight, use the Measurement Mode 2 Time-of-Flight calculation as shown in [Equation 1](#). For more information, refer to the TDC7201 data sheet ([SNAS686](#)).
- Use the values reported in the Measurement Result Registers ([Figure 10](#)) to validate the time-of-flight as approximately 19 μ s (assuming you follow the instructions as specified in [Section 5.1](#)).

$$\text{TOF}_n = [(\text{TIME}_1)(\text{normLSB}) + \text{offset}] + (\text{CLOCK_COUNT}_n)(\text{CLOCKperiod}) - [(\text{TIME}_{n+1})(\text{normLSB}) + \text{offset}]$$

$$\text{TOF}_n = \text{normLSB}(\text{TIME}_1 - \text{TIME}_{n+1}) + (\text{CLOCK_COUNT}_n)(\text{CLOCKperiod})$$

$$\text{normLSB} = \frac{(\text{CLOCKperiod})}{(\text{calCount})}$$

$$\text{calCount} = \frac{\text{CALIBRATION2} - \text{CALIBRATION1}}{(\text{CALIBRATION2_PERIODS}) - 1}$$

where

- TOF_n [second] = time-of-flight measurement from the START to the nth STOP
- normLSB [sec] = normalized LSB value from calibration
- TIME_1 = time 1 measurement given by the TDC7201 register address 0x10
- TIME_{n+1} = (n+1) time measurement given by the TDC7201 register addresses 0x12, 0x14, 0x16, 0x18, and 0x1A
- CLOCK_COUNT_n = nth clock count values in register addresses 0x11, 0x13, 0x15, 0x17, and 0x19
- CLOCKperiod [sec] = external CLOCK period
- offset [sec] = constant measurement offset
- CALIBRATION1 [count] = TDC count for first calibration cycle, located in register address 0x1B
- CALIBRATION2 [count] = TDC count for second calibration cycle, located in register address 0x1C
- $\text{CALIBRATION2_PERIODS}$ = calibration count bits, located in register address 0x01 (1)

$$\text{calCount} = \frac{\text{CALIBRATION2} - \text{CALIBRATION1}}{(\text{CALIBRATION2_PERIODS}) - 1} = \frac{(4354 - 2179)}{(2) - 1} = 2175$$

$$\text{normLSB} = \frac{(\text{CLOCKperiod})}{(\text{calCount})} = \frac{(1/8\text{MHz})}{2175} = 57.4\text{ps}$$

$$\text{TOF}_1 = \text{normLSB}(\text{TIME}_1 - \text{TIME}_2) + (\text{CLOCK_COUNT}_1)(\text{CLOCKperiod})$$

$$\text{TOF}_1 = (5.74 * 10^{-11})(1688 - 1667) + (152)(1/8\text{MHz})$$

$$\text{TOF}_1 = 19.001\mu\text{s} \quad (2)$$

5. START_EXT2/STOP_EXT2 Testing

(a) Modification to Input Signal Connections:

- (i) Disconnect USB-to-SMA cable connection to START_EXT1 (J5). Instead, reconnect channel 1 of the dual function generator to TDC7201EVM's START_EXT2 connector (J8).
- (ii) Disconnect USB-to-SMA cable connection to STOP_EXT1 (J4). Instead, reconnect channel 2 of the dual function generator to TDC7201EVM's STOP_EXT2 connector (J7). See Figure 4.

(b) Now repeat steps 1 through 4 from [Section 6](#) with the following modification to step 2: Click on the **TDC720x** tab and make sure the **TDC7201: Select TDCx** field is as shown in [Figure 11](#).

TDC7201: SELECT TDCx TDC2			
CONFIG1 (0x00) START No Effect	CONFIG2 (0x01) NUMBER OF STOPS Single	INTERRUPT STATUS (0x02) NEW_MEAS_INT Interrupt Not Detected	INTERRUPT MASK (0x03) NEW_MEAS_MASK Interrupt Enabled
MODE Measurement Mode 2	AVERAGING CYCLES 1 Meas Cycle	COARSE_CNTR_OVERFLOW_INT Overflow Not Detected	COARSE_CNTR_OVERFLOW_MASK Interrupt Enabled
START EDGE POLARITY Rising Edge	CALIBRATION 2 PERIODS 10 Clock Periods	CLOCK_CNTR_OVERFLOW_INT Overflow Not Detected	CLOCK_CNTR_OVERFLOW_MASK Interrupt Enabled
STOP EDGE POLARITY Rising Edge	<input type="button" value="R"/>	MEASUREMENT STARTED FLAG Measurement Not Started	<input type="button" value="R"/>
TRIGG EDGE POLARITY Rising Edge	COARSE_CNTR_OV_H (0x04) xFF	MEASUREMENT COMPLTD FLAG Measurement Incomplete	CLOCK_CNTR_STOP_MASK_H (0x08) x00
PARITY_EN Disabled	<input type="button" value="R"/>	<input type="button" value="R"/>	<input type="button" value="R"/>
FORCE CALIBRATION No Calibration after intrpt	COARSE_CNTR_OV_L (0x05) xFF	<input type="button" value="R"/>	CLOCK_CNTR_STOP_MASK_L (0x09) x00
<input type="button" value="R"/>	<input type="button" value="R"/>	<input type="button" value="R"/>	<input type="button" value="R"/>
CLOCK_CNTR_OV_H (0x06) xFF	CLOCK_CNTR_OV_L (0x07) xFF	<input type="button" value="READ ALL"/>	<input type="button" value="LOAD CONFIG"/>
<input type="button" value="R"/>	<input type="button" value="R"/>	<input type="button" value="SAVE CONFIG"/>	

Figure 11. Recommended TDC7201:TDC2 Register Configuration

7 Board Layout

NOTE: The board layout is not to scale. Figure 12 thru Figure 15 are intended to show how the board is laid out; it is not intended to be used for manufacturing.




Figure 12. TDC7201EVM Top Layer




Figure 13. TDC7201EVM Bottom Layer




Figure 14. TDC7201EVM Ground Plane





Figure 15. TDC7201EVM Power Plane

8 TDC7201EVM Schematic

The TDC7201EVM Schematic is shown in [Figure 16](#).



Copyright © 2016, Texas Instruments Incorporated

Figure 16. TDC7201EVM Schematic

9 Bill of Materials

Table 1. TDC7201EVM Bill of Materials

Designator	Qty	Value	Description	Package Reference	Part Number	Manufacturer
C1	1	10uF	CAP, CERM, 10 μ F, 6.3 V, +/- 20%, X5R, 0603	0603	C0603C106M9PACTU	Kemet
C2, C6	2	0.1uF	CAP, CERM, 0.1 μ F, 16 V, +/- 5%, X7R, 0603	0603	0603YC104JAT2A	AVX
C3, C5, C7	3	0.01uF	CAP, CERM, 0.01 μ F, 100 V, +/- 5%, X7R, 0603	0603	06031C103JAT2A	AVX
C4, C8	2	1uF	CAP, CERM, 1 μ F, 16 V, +/- 10%, X7R, 0603	0603	EMK107B7105KA-T	Taiyo Yuden
J1, J2	2		Receptacle, 100mil, 10x2, Gold, TH	10x2 Receptacle	PPPC102LFBN-RC	Sullins Connector Solutions
J3	1		Connector, TH, SMA	SMA	142-0701-201	Emerson Network Power
J4, J5, J6, J7, J8	5		Connector, End launch SMA, 50 ohm, SMT	End Launch SMA	142-0701-801	Johnson
JP1, JP3	2		Header, 100mil, 2x1, Gold, TH	2x1 Header	TSW-102-07-G-S	Samtec
R1, R2, R8, R9, R13	5	49.9	RES, 49.9, 1%, 0.1 W, 0603	0603	CRCW060349R9FKEA	Vishay-Dale
R3, R4, R10, R16, R18	5	0	RES, 0, 5%, 0.1 W, 0603	0603	CRCW06030000Z0EA	Vishay-Dale
R5, R6	2	10.0k	RES, 10.0 k, 1%, 0.1 W, 0603	0603	CRCW060310K0FKEA	Vishay-Dale
SH-JP1, SH-JP3	2	1x2	Shunt, 100mil, Gold plated, Black	Shunt	969102-0000-DA	3M
TP4, TP5, TP13, TP14	4	Black	Test Point, Multipurpose, Black, TH	Black Multipurpose Testpoint	5011	Keystone
TP9	1		Header, 100mil, 1pos, Gold, TH	Testpoint	TSW-101-07-G-S	Samtec
U1	1		Time-to-Digital Converter for Time-of-Flight Applications in LIDAR, Magnetostrictive and Flow Meters, ZAX0025A	ZAX0025A	TDC7201ZAXR	Texas Instruments
Y1	1		OSC, 8MHz, 15pF, SMD	OSC, 3.2x.85x5mm	ASFLMB-8.000MHZ-LY-T	Abrakon Corporation
FID1, FID2, FID3, FID4, FID5, FID6	0		Fiducial mark. There is nothing to buy or mount.	N/A	N/A	N/A
R7, R11, R12, R14, R15, R17	0	0	RES, 0, 5%, 0.1 W, 0603	0603	CRCW06030000Z0EA	Vishay-Dale
TP1, TP2, TP3, TP6, TP7, TP8	0		Header, 100mil, 1pos, Gold, TH	Testpoint	TSW-101-07-G-S	Samtec
TP10	0		Connector, TH, SMA	SMA	142-0701-201	Emerson Network Power

Revision History

NOTE: Page numbers for previous revisions may differ from page numbers in the current version.

Changes from Original (May 2016) to A Revision	Page
• Changed link to Gui	5
• Changed link to Gui	6

IMPORTANT NOTICE

Texas Instruments Incorporated and its subsidiaries (TI) reserve the right to make corrections, enhancements, improvements and other changes to its semiconductor products and services per JESD46, latest issue, and to discontinue any product or service per JESD48, latest issue. Buyers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All semiconductor products (also referred to herein as "components") are sold subject to TI's terms and conditions of sale supplied at the time of order acknowledgment.

TI warrants performance of its components to the specifications applicable at the time of sale, in accordance with the warranty in TI's terms and conditions of sale of semiconductor products. Testing and other quality control techniques are used to the extent TI deems necessary to support this warranty. Except where mandated by applicable law, testing of all parameters of each component is not necessarily performed.

TI assumes no liability for applications assistance or the design of Buyers' products. Buyers are responsible for their products and applications using TI components. To minimize the risks associated with Buyers' products and applications, Buyers should provide adequate design and operating safeguards.

TI does not warrant or represent that any license, either express or implied, is granted under any patent right, copyright, mask work right, or other intellectual property right relating to any combination, machine, or process in which TI components or services are used. Information published by TI regarding third-party products or services does not constitute a license to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

Reproduction of significant portions of TI information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. TI is not responsible or liable for such altered documentation. Information of third parties may be subject to additional restrictions.

Resale of TI components or services with statements different from or beyond the parameters stated by TI for that component or service voids all express and any implied warranties for the associated TI component or service and is an unfair and deceptive business practice. TI is not responsible or liable for any such statements.

Buyer acknowledges and agrees that it is solely responsible for compliance with all legal, regulatory and safety-related requirements concerning its products, and any use of TI components in its applications, notwithstanding any applications-related information or support that may be provided by TI. Buyer represents and agrees that it has all the necessary expertise to create and implement safeguards which anticipate dangerous consequences of failures, monitor failures and their consequences, lessen the likelihood of failures that might cause harm and take appropriate remedial actions. Buyer will fully indemnify TI and its representatives against any damages arising out of the use of any TI components in safety-critical applications.

In some cases, TI components may be promoted specifically to facilitate safety-related applications. With such components, TI's goal is to help enable customers to design and create their own end-product solutions that meet applicable functional safety standards and requirements. Nonetheless, such components are subject to these terms.

No TI components are authorized for use in FDA Class III (or similar life-critical medical equipment) unless authorized officers of the parties have executed a special agreement specifically governing such use.

Only those TI components which TI has specifically designated as military grade or "enhanced plastic" are designed and intended for use in military/aerospace applications or environments. Buyer acknowledges and agrees that any military or aerospace use of TI components which have **not** been so designated is solely at the Buyer's risk, and that Buyer is solely responsible for compliance with all legal and regulatory requirements in connection with such use.

TI has specifically designated certain components as meeting ISO/TS16949 requirements, mainly for automotive use. In any case of use of non-designated products, TI will not be responsible for any failure to meet ISO/TS16949.

Products

Audio	www.ti.com/audio
Amplifiers	amplifier.ti.com
Data Converters	dataconverter.ti.com
DLP® Products	www.dlp.com
DSP	dsp.ti.com
Clocks and Timers	www.ti.com/clocks
Interface	interface.ti.com
Logic	logic.ti.com
Power Mgmt	power.ti.com
Microcontrollers	microcontroller.ti.com
RFID	www.ti-rfid.com
OMAP Applications Processors	www.ti.com/omap
Wireless Connectivity	www.ti.com/wirelessconnectivity

Applications

Automotive and Transportation	www.ti.com/automotive
Communications and Telecom	www.ti.com/communications
Computers and Peripherals	www.ti.com/computers
Consumer Electronics	www.ti.com/consumer-apps
Energy and Lighting	www.ti.com/energy
Industrial	www.ti.com/industrial
Medical	www.ti.com/medical
Security	www.ti.com/security
Space, Avionics and Defense	www.ti.com/space-avionics-defense
Video and Imaging	www.ti.com/video

TI E2E Community

e2e.ti.com