

## LATCHING





**Latching Operation -**  
Push pedal to change contact state. When you release the pedal, the contacts remain in that state. Push again to return to original state.

## WITH E-STOP BUTTON



**Standard OFF-ON Operation -**  
Push pedal to change contact state. Release pedal to return to original state. With 2NC contact Emergency Stop



### Two pedal foot switch F2

| Article number | Designation     | Switching contacts |                 | Latching          |
|----------------|-----------------|--------------------|-----------------|-------------------|
|                |                 | Pedal 1 (left)     | Pedal 2 (right) |                   |
| 616.2840.655   | F2-SU1Y/SU2Z UN | 1NC / 1NO          | 2NC / 2NO       | (Pedal 1)         |
| 606.2610.018   | F2-U1Y/U1Y UN   | 1NC / 1NO          | 1NC / 1NO       | (Pedal 1+Pedal 2) |
| 606.2610.047   | F2-U1Y/U1Z UN   | 1NC / 1NO          | 1NC / 1NO       | (Pedal 1)         |

### Two pedal foot switch F2

| Article number | Designation       | Switching contacts |                 |
|----------------|-------------------|--------------------|-----------------|
|                |                   | Pedal 1 (left)     | Pedal 2 (right) |
| 616.2720.700   | F2-U2Z/U2Z NA2 UN | 2NC / 2NO          | 2NC / 2NO       |