

## MCP1630 Low-Cost NiMH Battery Charger Reference Design

#### Note the following details of the code protection feature on Microchip devices:

- Microchip products meet the specification contained in their particular Microchip Data Sheet.
- Microchip believes that its family of products is one of the most secure families of its kind on the market today, when used in the intended manner and under normal conditions.
- There are dishonest and possibly illegal methods used to breach the code protection feature. All of these methods, to our
  knowledge, require using the Microchip products in a manner outside the operating specifications contained in Microchip's Data
  Sheets. Most likely, the person doing so is engaged in theft of intellectual property.
- Microchip is willing to work with the customer who is concerned about the integrity of their code.
- Neither Microchip nor any other semiconductor manufacturer can guarantee the security of their code. Code protection does not mean that we are guaranteeing the product as "unbreakable."

Code protection is constantly evolving. We at Microchip are committed to continuously improving the code protection features of our products. Attempts to break Microchip's code protection feature may be a violation of the Digital Millennium Copyright Act. If such acts allow unauthorized access to your software or other copyrighted work, you may have a right to sue for relief under that Act.

Information contained in this publication regarding device applications and the like is provided only for your convenience and may be superseded by updates. It is your responsibility to ensure that your application meets with your specifications. MICROCHIP MAKES NO REPRESENTATIONS WARRANTIES OF ANY KIND WHETHER EXPRESS OR IMPLIED, WRITTEN OR ORAL, STATUTORY OR OTHERWISE, RELATED TO THE INFORMATION, INCLUDING BUT NOT LIMITED TO ITS CONDITION. QUALITY, PERFORMANCE, MERCHANTABILITY FITNESS FOR PURPOSE. Microchip disclaims all liability arising from this information and its use. Use of Microchip devices in life support and/or safety applications is entirely at the buyer's risk, and the buyer agrees to defend, indemnify and hold harmless Microchip from any and all damages, claims, suits, or expenses resulting from such use. No licenses are conveyed, implicitly or otherwise, under any Microchip intellectual property rights.

#### **Trademarks**

The Microchip name and logo, the Microchip logo, Accuron, dsPIC, KEELOQ, KEELOQ logo, microID, MPLAB, PIC, PICmicro, PICSTART, PRO MATE, PowerSmart, rfPIC, and SmartShunt are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.


AmpLab, FilterLab, Linear Active Thermistor, Migratable Memory, MXDEV, MXLAB, PS logo, SEEVAL, SmartSensor and The Embedded Control Solutions Company are registered trademarks of Microchip Technology Incorporated in the U.S.A.

Analog-for-the-Digital Age, Application Maestro, CodeGuard, dsPICDEM, dsPICDEM.net, dsPICworks, ECAN, ECONOMONITOR, FanSense, FlexROM, fuzzyLAB, In-Circuit Serial Programming, ICSP, ICEPIC, Mindi, MiWi, MPASM, MPLAB Certified logo, MPLIB, MPLINK, PICkit, PICDEM, PICDEM.net, PICLAB, PICtail, PowerCal, PowerInfo, PowerMate, PowerTool, REAL ICE, rfLAB, rfPICDEM, Select Mode, Smart Serial, SmartTel, Total Endurance, UNI/O, WiperLock and ZENA are trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

SQTP is a service mark of Microchip Technology Incorporated in the U.S.A.

All other trademarks mentioned herein are property of their respective companies.

© 2007, Microchip Technology Incorporated, Printed in the U.S.A., All Rights Reserved.



Microchip received ISO/TS-16949:2002 certification for its worldwide headquarters, design and wafer fabrication facilities in Chandler and Tempe, Arizona, Gresham, Oregon and Mountain View, California. The Company's quality system processes and procedures are for its PIC® MCUs and dsPIC® DSCs, KEELOQ® code hopping devices, Serial EEPROMs, microperipherals, nonvolatile memory and analog products. In addition, Microchip's quality system for the design and manufacture of development systems is ISO 9001:2000 certified.

# QUALITY MANAGEMENT SYSTEM CERTIFIED BY DNV ISO/TS 16949:2002



### **Table of Contents**

Preface	1
Introduction	1
Document Layout	1
Conventions Used in this Guide	2
Recommended Reading	3
The Microchip Web Site	3
Customer Support	
Document Revision History	4
Chapter 1. Product Overview	5
1.1 Introduction	
1.2 What is the MCP1630 Low Cost NiMH Battery Charger Reference Design	n? 6
What the MCP1630 Low Cost NiMH Battery Charger Reference Design Kit includes	6
Chapter 2. Installation and Operation	7
2.1 Introduction	7
2.2 Features	7
2.3 Getting Started	8
Appendix A. Schematic and Layouts	11
A.1 Introduction	11
A.2 Board – Schematic	12
A.3 Board – Top Silk Layer	13
A.4 Board – Top Metal Layer	14
A.5 Board – Bottom Metal Layer	15
Appendix B. Bill Of Materials (BOM)	17
Appendix C. Demo Board Firmware	19
C.1 Device Firmware Flowchart - Page 1	19
C.2 Device Firmware Flowchart - Page 2	20
Worldwide Sales and Service	22

MCP1630 Low-Cost NiMH Battery Charger Reference Design					
NOTES:					



#### **Preface**

#### **NOTICE TO CUSTOMERS**

All documentation becomes dated, and this manual is no exception. Microchip tools and documentation are constantly evolving to meet customer needs, so some actual dialogs and/or tool descriptions may differ from those in this document. Please refer to our web site (www.microchip.com) to obtain the latest documentation available.

Documents are identified with a "DS" number. This number is located on the bottom of each page, in front of the page number. The numbering convention for the DS number is "DSXXXXXA", where "XXXXXX" is the document number and "A" is the revision level of the document.

For the most up-to-date information on development tools, see the MPLAB<sup>®</sup> IDE on-line help. Select the Help menu, and then Topics to open a list of available on-line help files.

#### INTRODUCTION

This chapter contains general information that will be useful to know before using the MCP1630 Low-Cost NiMH Battery Charger Reference Design. Items discussed in this chapter include:

- · Document Layout
- · Conventions Used in this Guide
- · Recommended Reading
- The Microchip Web Site
- Customer Support
- · Document Revision History

#### **DOCUMENT LAYOUT**

This document describes how to use the MCP1630 Low-Cost NiMH Battery Charger Reference Design as a development tool. The manual layout is as follows:

- Chapter 1. "Product Overview" Important information about the MCP1630 Low-Cost NiMH Battery Charger Reference Design.
- Chapter 2. "Installation and Opation" Includes instructions on how to get started with this user's guide and a description of how to use the MCP1630 Low-Cost NiMH Battery Charger Reference Design.
- Appendix A. "Schematic and Layouts" Shows the schematic and layout diagrams for the MCP1630 Low-Cost NiMH Battery Charger Reference Design.
- Appendix B. "Bill Of Materials (BOM)" Lists the parts used to build the MCP1630 Low-Cost NiMH Battery Charger Reference Design.
- Appendix C. "Demo Board Firmware" Provides information about the application firmware and source code.

### MCP1630 Low-Cost NiMH Battery Charger Reference Design

#### **CONVENTIONS USED IN THIS GUIDE**

This manual uses the following documentation conventions:

#### **DOCUMENTATION CONVENTIONS**

Description	Represents	Examples	
Arial font:			
Italic characters	Referenced books	MPLAB <sup>®</sup> IDE User's Guide	
	Emphasized text	is the only compiler	
Initial caps	A window	the Output window	
	A dialog	the Settings dialog	
	A menu selection	select Enable Programmer	
Quotes	A field name in a window or dialog	"Save project before build"	
Underlined, italic text with right angle bracket	A menu path	File>Save	
Bold characters	A dialog button	Click <b>OK</b>	
	A tab	Click the <b>Power</b> tab	
N'Rnnnn	A number in verilog format, where N is the total number of digits, R is the radix and n is a digit.	4'b0010, 2'hF1	
Text in angle brackets < >	A key on the keyboard	Press <enter>, <f1></f1></enter>	
Courier New font:			
Plain Courier New	Sample source code	#define START	
	Filenames	autoexec.bat	
	File paths	c:\mcc18\h	
	Keywords	_asm, _endasm, static	
	Command-line options	-Opa+, -Opa-	
	Bit values	0, 1	
	Constants	0xff, 'A'	
Italic Courier New	A variable argument	file.o, where file can be any valid filename	
Square brackets []	Optional arguments	<pre>mcc18 [options] file [options]</pre>	
Curly brackets and pipe character: {   }	Choice of mutually exclusive arguments; an OR selection	errorlevel {0 1}	
Ellipses	Replaces repeated text	<pre>var_name [, var_name]</pre>	
	Represents code supplied by user	void main (void) { }	

#### RECOMMENDED READING

This user's guide describes how to use MCP1630 Low-Cost NiMH Battery Charger Reference Design. Other useful documents are listed below. The following Microchip documents are available and recommended as supplemental reference resources.

MCP1630/MCP1630V Data Sheet, "High-Speed, Microcontroller-Adaptable, Pulse Width Modulator" (DS21896)

This data sheet provides detailed information regarding the MCP1630/MCP1630V product family.

PIC12F683 Data Sheet, "8-Pin Flash-Based, 8-Bit CMOS Microcontrollers with Nano Watt Technology" (DS41211)

This data sheet provides detailed information regarding the PIC12F683 product family.

AN960 Application Note, "New Components and Design Methods Bring Intelligence to Battery Charger Applications" (DS00960)

#### THE MICROCHIP WEB SITE

Microchip provides online support via our web site at www.microchip.com. This web site is used as a means to make files and information easily available to customers. Accessible by using your favorite Internet browser, the web site contains the following information:

- Product Support Data sheets and errata, application notes and sample programs, design resources, user's guides and hardware support documents, latest software releases and archived software
- General Technical Support Frequently Asked Questions (FAQs), technical support requests, online discussion groups, Microchip consultant program member listing
- Business of Microchip Product selector and ordering guides, latest Microchip press releases, listing of seminars and events, listings of Microchip sales offices, distributors and factory representatives

#### **CUSTOMER SUPPORT**

Users of Microchip products can receive assistance through several channels:

- Distributor or Representative
- · Local Sales Office
- Field Application Engineer (FAE)
- · Technical Support

Customers should contact their distributor, representative or field application engineer for support. Local sales offices are also available to help customers. A listing of sales offices and locations is included in the back of this document.

Technical support is available through the web site at: http://support.microchip.com

### MCP1630 Low-Cost NiMH Battery Charger Reference Design

#### **DOCUMENT REVISION HISTORY**

Revision A (February 2007)

· Initial Release of this Document.



### **Chapter 1. Product Overview**


#### 1.1 INTRODUCTION

The MCP1630 Low-Cost NiMH Battery Charger Reference Design is used to charge three series cell NiMH or NiCd batteries. The board uses the MCP1630 high-speed analog PWM and PIC12F683 to generate the charge algorithm for NiMH or NiCd batteries.

The MCP1630 Low-Cost NiMH Battery Charger Reference Design is used to evaluate Microchip's MCP1630 in a SEPIC power converter application. As provided, the MCP1630 Low-Cost NiMH Battery Charger Reference Design is capable of charging a three series cell NiMH battery pack from an input voltage of 6V to 14V. The MCP1630 Low-Cost NiMH Battery Charger Reference Design provides a constant current charge with preconditioning, cell temperature monitoring and battery pack fault monitoring. Also, the charger provides a status or fault indication. The MCP1630 Low-Cost NiMH Battery Charger Reference Design automatically detects the insertion or removal of a battery pack.

This chapter covers the following topics.

- · What is the MCP1630 Low Cost NiMH Battery Charger Reference Design?
- What the MCP1630 Low Cost NiMH Battery Charger Reference Design Kit includes.



**FIGURE 1-1:** MCP1630 Low Cost NiMH Battery Charger Reference Design Block Diagram.

#### MCP1630 Low-Cost NiMH Battery Charger Reference Design

## 1.2 WHAT IS THE MCP1630 LOW COST NIMH BATTERY CHARGER REFERENCE DESIGN?

The MCP1630 Low-Cost NiMH Battery Charger Reference Design is a complete stand-alone constant current battery charger for a three series cell NiMH or NiCd battery pack. Different battery chemistries (i.e. Li-Ion batteries connected in series) can be charged with minor modifications to the firmware or with the MCP1630 Low-Cost NiMH Battery Charger Reference Design. This board utilizes Microchip's MCP1630 (high-speed PIC® MCU PWM MSOP8), MCP6292 (Dual op-amp MSOP8), and PIC12F683 (Flash MCU SOIC8). The input voltage range for the demo board is 6V to 14V. The output is capable of charging at a fast charge rate of 1.3A constant current. An input terminal block is provided to apply the input voltage to the charger. An output header is also provided as a means to connect the external battery pack or simulated battery load and external 10K thermistor. A programming header is available for updating the firmware contained in the PIC12F683.

## 1.3 WHAT THE MCP1630 LOW COST NIMH BATTERY CHARGER REFERENCE DESIGN KIT INCLUDES

This MCP1630 Low Cost NiMH Battery Charger Reference Design kit includes:

- The MCP1630 Low-Cost NiMH Battery Charger Reference Design Board, (102-00127)
- Analog and Interface Products Demonstration Boards CD-ROM (DS21912)
  - MCP1630 Low-Cost NiMH Battery Charger Reference Design User's Guide, (DS51648)



### Chapter 2. Installation and Operation

#### 2.1 INTRODUCTION

The MCP1630 Low-Cost NiMH Battery Charger Reference Design demonstrates Microchip's high-speed Pulse Width Modulator (PWM) (the MCP1630) used in a battery charger application. When used in conjunction with a microcontroller, the MCP1630 will control the power system duty cycle to provide output voltage or current regulation. The PIC12F683 microcontroller can be used to regulate output voltage or current, switching frequency and maximum duty cycle. The MCP1630 generates duty cycle and provides fast overcurrent protection based off various external inputs. External signals include the input oscillator, the reference voltage, the feedback voltage and the current sense. The output signal is a square-wave pulse. The power train used for the MCP1630 Low-Cost NiMH Battery Charger Reference Design is a Single-Ended Primary Inductive Converter (SEPIC). The PIC12F683 microcontroller is programmable, allowing the user to modify or develop their own firmware routines to further evaluate the MCP1630 Low-Cost NiMH Battery Charger Reference Design in this application.


#### 2.2 FEATURES

The MCP1630 Low-Cost NiMH Battery Charger has the following features:

- · Programmed parameters modified in firmware
- · Factory Settings:
  - Preconditioning Charge Current =170 mA
  - Preconditioning Threshold = 3V
  - Constant Current Fast Charge = 1.35A
  - Charge Termination based on delta V<sub>BATT</sub> / delta time
  - Charge Termination based on delta + T<sub>BATT</sub> / delta time, with external thermistor installed
- Top Off Charge Current = 130 mA for 1 Hour
- Overvoltage protection (battery removed)
- · Overcharge protection to prevent damaging the battery
- Overcurrent protection in the event of a shorted battery
- · Battery reversal protection
- · Input short circuit protection
- Overtemperature protection to prevent the battery from reaching too high a temperature during charge
- Soft-start capability by holding the reference voltage low during power-up
- The MCP1630 Low-Cost NiMH Battery Charger has the flexibility to optimize the charging algorithm for new battery technology, different battery chemistries or different battery pack configurations
- Proprietary features can be added by modifying the firmware contained in the PIC12F683
- The factory-programmed source code is available
- · Ability to adapt to environmental effects, such as ambient temperature

#### 2.3 GETTING STARTED

The MCP1630 Low-Cost NiMH Battery Charger is fully assembled and tested for charging three series cell NiMH batteries. The charge termination is based on a negative slope in battery voltage or a positive slope in battery pack temperature, (when external thermistor is installed). This board requires the use of an external voltage source to charge the series connected batteries with a range of +6V to +14V input. An external load and thermistor is also required to evaluate the charger reference design.



**FIGURE 2-1:** MCP1630 Low-Cost NiMH Battery Charger Reference Design Charge Profile.

#### 2.3.1 Power Input and Output Connection

#### 2.3.1.1 POWERING THE MCP1630 LOW-COST NIMH BATTERY CHARGER

- 1. Apply the input voltage to the input terminal block, J1. The input voltage source should be limited to the 0V to +14V range. For nominal operation the input voltage should be between +6V and +14V.
- 2. Connect the positive side of the input source (+) to pin 1 of J1. Connect the negative or return side (-) of the input source to pin 2 of J1. Refer to Figure 2-2.




FIGURE 2-2: Setup Configuration Diagram.

## 2.3.1.2 APPLYING A LOAD TO THE MCP1630 LOW-COST NIMH BATTERY CHARGER REFERENCE DESIGN

- 1. To apply a load to the MCP1630 Low-Cost Li-lon Battery Charger, the positive side of the load (B+) should be connected to pin 1 of J2. The negative side of the load (B-) should be connected to pin 5 of J2. Care should be taken when using electronic loads or ground referenced loads.
- 2. A thermistor referenced to (B-) in the battery pack should be utilized, recommended EPCOS Inc. PN B57509m103A5. If a thermistor is not available or not desired, a 10 k $\Omega$  resistor should be placed between pins 4 and 5 of the battery header (J2).
- 3. The installed firmware will prevent the board from entering the 1.3A Fast Charge mode, if the battery terminal voltage is less than 2V. During power-up, the board will always trickle charge first, so using a purely resistive load will not work for trickle and fast-charge current. The best way to evaluate the charger is to use a three series cell NiMH 2,200 mA/hour batteries, or the recommended simulated battery load. Refer to Figure 2-3 before applying a load to the MCP1630 Low-Cost NiMH Battery Charger Reference Design.




FIGURE 2-3: Simulated Battery Load.

#### 2.3.1.3 STATUS LED

1. The MCP1630 Low-Cost NiMH Battery Charger has an LED to indicate charge status or fault status. Table 2-1 represents the state of the LED during various states of the charge cycle.

TABLE 2-1: STATUS OUTPUT

CHARGE CYCLE STATE	LED
Qualification	OFF
Preconditioning	ON
Constant Current Fast Charge	ON
Top Off Charge	ON
Charge Complete	OFF
Safety Timer Fault	Flashing (2 Hz, 50% duty cycle)
Cell Temperature Invalid	Flashing (1 Hz, 50% duty cycle)
Battery Disconnected	OFF
Input Power Removed	OFF

#### 2.3.1.4 PROGRAMMING

Header J3 is provided for in-system circuit programming.




### Appendix A. Schematic and Layouts

#### A.1 INTRODUCTION


This appendix contains the following schematics and layouts for the MCP1630 Low-Cost NiMH Battery Charger Reference Design:

- · Board Schematic
- · Board Top Silk Layer
- Board Top Metal Layer
- Board Bottom Silk Layer
- Board Bottom Metal Layer


#### A.2 BOARD - SCHEMATIC




#### A.3 BOARD - TOP SILK LAYER



#### A.4 BOARD - TOP METAL LAYER



#### A.5 BOARD - BOTTOM METAL LAYER



CP1630 Low-Cost NiMH Battery Charger Reference D	esign
TES:	



### **Appendix B. Bill Of Materials (BOM)**

TABLE B-1: BILL OF MATERIALS (BOM)

Qty	Reference	Description	Manufacturer	Part Number
3	C1, C2, C4	10uF, X5R Ceramic, 25V, 1206	Panasonic®-ECG	ECJ-3YB1E106M
1	C3	1uF, X7R Ceramic, 25V, 1206	Panasonic-ECG	ECJ-3YB1E105K
5	C5, C10, C12, C13	0.1uF, X7R Ceramic, 16V, 0805	Panasonic-ECG	ECJ-2VB1C104K
2	C6, C7	1500pF, X7R Ceramic, 100V, 0805	Panasonic-ECG	ECJ-2VB2A152K
1	C8	22pF, NPO Ceramic, 50V, 0805	Panasonic-ECG	ECJ-2VC1H220J
2	C9, C14	1uF, X5R Ceramic, 16V, 0805	Panasonic-ECG	ECJ-2FB1C105K
1	D1	3.0A, 30V Schottky Diode, SMA	Toshiba	CMS01 (TE12L)
1	D2	Green LED, 0805	Lumex <sup>®</sup> Opto	SML-LXT0805GW-TR
1	J1	Connector Terminal Block, 2 Pos., 2.54mm, TB254-2	Phoenix Contact	1725656
1	J2	Connector Header, 5 Pos., 2.54mm, Friction Lock, HDR1X5-FL	Molex	22-23-2051
1	J3	Connector Header, 5 Pos., 2.54mm, HDR1X5	Molex	22-03-2051
1	L1	10uH, Coupled Inductor, DRQ127	Coiltronics	DRQ127-100
1	PCB	RoHS Compliant Bare PCB, MCP1630 Low-Cost NiMH Battery Charger Reference Design	_	104-000127
1	Q1	N-Channel MOSFET, SOIC8	International Rectifier	IRF7807V
4	R1, R2, R3, R4	0.22, 1/4W, Chip Resistor, 1206	Panasonic-ECG	ERJ-8RQFR22V
4	R5, R7, R11, R16, R18	10.0k, 1/10W, Chip Resistor, 0805	Panasonic-ECG	ERJ-6ENF1002V
1	R6, R20	100k, 1/10W, Chip Resistor, 0805	Panasonic-ECG	ERJ-6ENF1003V
1	R8	47.5k, 1/10W, Chip Resistor, 0805	Panasonic-ECG	ERJ-6ENF4752V
5	R9, R10, R14, R17, R21	1.00k, 1/10W, Chip Resistor, 0805	Panasonic-ECG	ERJ-6ENF1001V
2	R12, R13	422k, 1/10W, Chip Resistor, 0805	Panasonic-ECG	ERJ-6ENF4223V
1	R15 ,R19	39.2k, 1/10W, Chip Resistor, 0805	Panasonic-ECG	ERJ-6ENF3922V
1	U2	Dual Operational Amplifier 10MHz, MSOP8	Microchip Technology Inc	MCP6292-E/MS
1	U3	PWM Building Block, MSOP8	Microchip Technology Inc	MCP1630-E/MS
1	U4	Enhanced FLASH Microcontroller, SOIC8	Microchip Technology Inc	PIC12F683-I/SN
1	U5	5.0V, 250mA, Voltage Regulator, SOT23	Microchip Technology Inc	MCP17025002E/CB

**Note 1:** The components listed in this Bill of Materials are representative of the PCB assembly. The released BOM used in manufacturing uses all RoHS-compliant components.

MCP1630 Low-Cost NiMH Battery Charger Reference Design			
NOTES:			



### Appendix C. Demo Board Firmware

#### C.1 DEVICE FIRMWARE FLOWCHART - PAGE 1

For the latest copy of the MCP1630 Low-Cost NiMH Battery Charger Reference Design firmware, visit our website at www.microchip.com.




FIGURE C-1: Firmware Flowchart, page 1.

#### C.2 DEVICE FIRMWARE FLOWCHART - PAGE 2

For the latest copy of the MCP1630 Low-Cost NiMH Battery Charger Reference Design firmware, visit our website at www.microchip.com.




FIGURE C-2: Firmware Flowchart, page 2.

1101000		Firmware
	BUALL	PITTIMATO
DGIIIO	DUGIU	

	Demo Board Firmware
NOTES:	



#### WORLDWIDE SALES AND SERVICE

#### **AMERICAS**

**Corporate Office** 

2355 West Chandler Blvd. Chandler, AZ 85224-6199 Tel: 480-792-7200 Fax: 480-792-7277 Technical Support:

http://support.microchip.com

Web Address: www.microchip.com

Atlanta

Duluth, GA Tel: 678-957-9614 Fax: 678-957-1455

**Roston** 

Westborough, MA Tel: 774-760-0087 Fax: 774-760-0088

Chicago Itasca, IL

Tel: 630-285-0071 Fax: 630-285-0075

**Dallas** 

Addison, TX Tel: 972-818-7423 Fax: 972-818-2924

Detroit

Farmington Hills, MI Tel: 248-538-2250 Fax: 248-538-2260

Kokomo

Kokomo, IN Tel: 765-864-8360 Fax: 765-864-8387

Los Angeles

Mission Viejo, CA Tel: 949-462-9523 Fax: 949-462-9608

Santa Clara

Santa Clara, CA Tel: 408-961-6444 Fax: 408-961-6445

**Toronto** 

Mississauga, Ontario, Canada

Tel: 905-673-0699 Fax: 905-673-6509

#### ASIA/PACIFIC

**Asia Pacific Office** 

Suites 3707-14, 37th Floor Tower 6, The Gateway Habour City, Kowloon Hong Kong

Tel: 852-2401-1200 Fax: 852-2401-3431

Australia - Sydney Tel: 61-2-9868-6733 Fax: 61-2-9868-6755

China - Beijing

Tel: 86-10-8528-2100 Fax: 86-10-8528-2104

China - Chengdu Tel: 86-28-8665-5511

Fax: 86-28-8665-7889

China - Fuzhou

Tel: 86-591-8750-3506 Fax: 86-591-8750-3521

China - Hong Kong SAR Tel: 852-2401-1200

Fax: 852-2401-3431

China - Qingdao Tel: 86-532-8502-7355

Fax: 86-532-8502-7205

China - Shanghai Tel: 86-21-5407-5533

Fax: 86-21-5407-5066

China - Shenyang

Tel: 86-24-2334-2829 Fax: 86-24-2334-2393

China - Shenzhen

Tel: 86-755-8203-2660 Fax: 86-755-8203-1760

China - Shunde

Tel: 86-757-2839-5507 Fax: 86-757-2839-5571

China - Wuhan

Tel: 86-27-5980-5300 Fax: 86-27-5980-5118

China - Xian

Tel: 86-29-8833-7250 Fax: 86-29-8833-7256

#### ASIA/PACIFIC

India - Bangalore

Tel: 91-80-4182-8400 Fax: 91-80-4182-8422

India - New Delhi

Tel: 91-11-4160-8631 Fax: 91-11-4160-8632

India - Pune

Tel: 91-20-2566-1512 Fax: 91-20-2566-1513

Japan - Yokohama

Tel: 81-45-471- 6166 Fax: 81-45-471-6122

Korea - Gumi

Tel: 82-54-473-4301 Fax: 82-54-473-4302

Korea - Seoul

Tel: 82-2-554-7200 Fax: 82-2-558-5932 or 82-2-558-5934

Malaysia - Penang Tel: 60-4-646-8870

Fax: 60-4-646-5086

Philippines - Manila

Tel: 63-2-634-9065 Fax: 63-2-634-9069

Singapore Tel: 65-6334-8870

Fax: 65-6334-8850 Taiwan - Hsin Chu

Tel: 886-3-572-9526 Fax: 886-3-572-6459

Taiwan - Kaohsiung

Tel: 886-7-536-4818 Fax: 886-7-536-4803

Taiwan - Taipei

Tel: 886-2-2500-6610 Fax: 886-2-2508-0102 Thailand - Bangkok

Tel: 66-2-694-1351

Fax: 66-2-694-1350

#### **EUROPE**

Austria - Wels

Tel: 43-7242-2244-39 Fax: 43-7242-2244-393

Denmark - Copenhagen

Tel: 45-4450-2828 Fax: 45-4485-2829

France - Paris

Tel: 33-1-69-53-63-20 Fax: 33-1-69-30-90-79

Germany - Munich

Tel: 49-89-627-144-0 Fax: 49-89-627-144-44

Italy - Milan

Tel: 39-0331-742611 Fax: 39-0331-466781

Netherlands - Drunen

Tel: 31-416-690399 Fax: 31-416-690340 Spain - Madrid

Tel: 34-91-708-08-90

Fax: 34-91-708-08-91 UK - Wokingham

Tel: 44-118-921-5869 Fax: 44-118-921-5820

12/08/06