


Freescale and the Freescale logo are trademarks of Freescale Semiconductor, Inc., Reg. U.S. Pat. & Tm. Off. All other product or service names are the property of their respective owners. © 2015 Freescale Semiconductor, Inc. FRDMK22FAGM01QRC REV 0 920-76667 REV A



For more information, visit [freescale.com/sensortoolbox](http://freescale.com/sensortoolbox)

FRDM-K22F-AGM01

FRDM-K22F-AGM01



FRDM-K22F-AGM01

## Quick Reference Card

### 9-axis Sensor Toolbox Development Board

Enabled for sensor fusion with FXAS21002C 3-axis gyroscope, FXOS8700C 6-axis integrated e-compass, and Freescale Freedom FRDM-K22F development board



#### Get Started

Download tools and documentation under **Jump-Start Your Design** at [freescale.com/sensortoolbox](http://freescale.com/sensortoolbox)



FREESCALE FREEDOM PLATFORM

- 1 Verify package contents:
  - FRDM-K22F/FRDM-STBC-AGM01 assembly
  - USB cable
- 2 Download the mbed Windows serial port driver:  
[developer.mbed.org/handbook/Windows-serial-configuration](http://developer.mbed.org/handbook/Windows-serial-configuration)
- 3 Plug one end of a USB cable into the SDA port on the assembly. Plug the other end of the cable into the USB port on the computer.
- 4 Download and install the latest Sensor Toolbox software at:  
[freescale.com/sensortoolbox](http://freescale.com/sensortoolbox)
- 5 Start the Sensor Toolbox software.


For more information, go to:  
[freescale.com/sensortoolbox](http://freescale.com/sensortoolbox)

FXOS8700C 6-axis sensor with integrated linear accelerometer and magnetometer  
16 QFN (3 mm x 3 mm x 1.2 mm)

INT1-8700 - 3  
INT2-8700 - 5  
INT1-21002 - 6

INT2-21002 - 1  
SPI-CSB-21002 - 3  
SPI-MOSI - 4  
SA0-MISO - 5  
SPI-SCLK - 6  
GND - 7

I2C\_SDA0 - 9  
I2C\_SCL0 - 10



6 - I2C-SCL1  
5 - I2C-SDA1  
4 - RST-GPIO  
3 - SPI-CSB-8700

7 - GND  
6 - GND

4 - VDD  
3 - RST-MCU  
2 - VDD

FXAS21002C 3-axis digital angular rate gyroscope  
24 QFN (4 mm x 4 mm x 1 mm)

Test points (18 places)

Get to Know the FRDM-K22F-AGM01



Learn more at [freescale.com/sensortoolbox](http://freescale.com/sensortoolbox)